



ASSEMBLY GUIDE

OSF PROFILE

SADEV BALUSTRADE CONCEPT RANGE



ASSEMBLY GUIDE VIDEO

ORDER CONFORMITY

We advise you to read this manual completely and carefully before working on the equipment.

Using the delivery note, check the conformity of the delivery before any other intervention.

ACTIVATE YOUR PRODUCT WARRANTY

Register directly on our website www.sadev.com/maintenance-and-warranty





Product description





Low wedge (12 copies)



Thickness shim (12 copies)



High wedge (12 copies)



Screw (12 copies)



Complete wedge (12 copies)

Number on the wedge	Reference	Glass composition	Glazing thickness [min.; max.]
3	0090SF-K12-0606	6.6	12.4 > 13.9
4	0090SF-K12-0808	8.8	16.2 > 17.6
1	0090SF-K12-1010	10.10	21.2 > 21.6

IMPORTANT



Control that the glass thickness is compatible with the wedges before installing it in the rail.

GUIDLINES

The balustrade assembly must comply with these assembly instructions, as well as with the usual safety and usage precautions.

Any modification or degradation of SADEV's products disengage the responsibility of our company.



Available on sadev.com Q

OSF° 🗊

SUMMARY

A	RAIL FIXING	8
B	PROFILE CONNECTION	10
0	INSTALLATION OF LOW WEDGES	11
D	SNAP-FIT GASKET AND GLASS INSTALLATION	12
	GLASS SPACER	13
	THICKNESS SHIMS INSTALLATION	14
G	HIGH WEDGES INSTALLATION	15
	CLADDING AND GASKET INSTALLATION ON THE ACCESSIBLE SIDE	16
•	END CAPS INSTALLATION	17
•	HANDRAIL INSTALLATION	18
K	REMOVING THE WEDGES MAINTENANCE	21

Tools required for assembly


- ROTARY HAMMER
- DRILL BITS ADAPTED TO THE STRUCTURE AND FASTENING COMPONENTS drilled profile 15mm diameter.
- TIGHTENING TOOL AND TORQUE CONTROL according to the type of dowel used.
- DYNAMOMETRIC SCREWDRIVER PACK + TORX BIT Ref.: OUT-TRVS-2NM - Tightening torque: 2 Nm.
- CORDLESS SCREWDRIVER
- MALLET
- SADEV CLEANING SET Ref.: 70UT-KITNET.
- OSF PROFILE LEVELING SHIMS
- LEVEL TOOL





HOW TO MADE A WATER DRAINAGE

Water drainage in the OSF guadrail is carried out by drilling the alluminium rail and/or the finishing plugs according to the technical drawings below.

As the rail must be laid straight (without deformation), the water drains off naturally on both sides of it. Depending on the situation, \emptyset 8mm holes can be drilled on site in the plug and/or profile for water drainage.










Floor mounting



HOW TO MADE A WATER DRAINAGE







Lateral mounting



RAIL AND CLADDING EXPANSION INFORMATIONS



Expansion is taken into account to ensure that the rails and claddings are held securely in place. The building's expansion gasket must be respected in the balustrade assembly.

During the balustrade assembly, you must consider the coefficient of thermal expansion.


What does it refer?

The coefficient of thermal expansion is the expansion at constant pressure of the railing caused by its heating or cooling.


ALUMINUM							
2 500mm		Maximum profile temperature					
Profile temperature during assembly		40°C / 104°F	50°C / 122°F	60°C / 140°F	70°C / 158°F	80°C / 176°F	
	-20°C/-4°F	4mm	4mm	5mm	5mm	6mm	
	-10°C/-14°F	3mm	4mm	4mm	5mm	5mm	
	0°C/32°F	3mm	3mm	4mm	4mm	5mm	
	10°C/50°F	2mm	3mm	3mm	4mm	4mm	
	20°C/68°F	1mm	2mm	3mm	3mm	4mm	
	30°C/86°F	1mm	1mm	2mm	3mm	3mm	
5 000mm Maxim			Maximu	um profile temperature			
		40°C / 104°F	50°C / 122°F	60°C / 140°F	70°C / 158°F	80°C / 176°F	
	-20°C/-4°F	7mm	8mm	9mm	11mm	12mm	
Profile temperature during assembly	-10°C/-14°F	6mm	7mm	8mm	9mm	11mm	
	0°C/32°F	5mm	6mm	7mm	8mm	9mm	
	10°C/50°F	4mm	5mm	6mm	7mm	8mm	
	20°C/68°F	3mm	4mm	5mm	6mm	7mm	
	30°C/86°F	1mm	3mm	4mm	5mm	6mm	

OSF[®]





1 - Check the flatness and conformity of the support with a ruler.



2 - Drill the support with a tool adapted to it.


INFORMATIONS

Possible supports: concrete, wood, metal, others....

The support must be able to support the loads induced by the balustrade.


OSF ®





3 - If it's an uneven surface, level the profile by adding our OSF profile leveling shims.

These wedges must be placed at the level of the fasteners (it is possible to put several of them).



4 - Adjust and fix the rail with the appropriate wrench to the fixing pins.

Respect the tightening torque and the mounting recommendations recommended by the manufacturer.



CAUTION

Be sure to take into account the expansion gaps between the OSF profiles and the support.

MORE INFORMATION ON PAGE 6.


OSF ®




LATERAL MOUNTING



CAUTION: Be sure to take into account the expansion gaps between the OSF profiles and the support. MORE INFORMATION ON PAGE 6.



- 1 Drill the support with a tool adapted to it.
- 2 If the support is irregular, level the profile by adding our osf profile leveling shims.
 These wedges must be placed at the level of the fasteners (it is possible to put several of them).




3 - Adjust and fix the rail with the appropriate wrench to the fixing pins.

Respect the tightening torque and the mounting recommendations recommended by the manufacturer.




B PROFILE CONNECTION




1 - Fit 2 SADEV pins connector in the rail section holes.

Location of spring pins




0090SF-R70 / 0090SF-R80




2 - Connect the rails together by using a mallet.











- 1 Cleaning the rail with the Sadev cleaning set. Ref. : 70UT-KITNET
- 2 Install the wedge in the rail.



SNAP FIT GASKET AND GLASS INSTALLATION




1 - Press the Snap-fit gascket into the non accessible side.



2 - Lift the glass pannel inside the wedges.







1 - Remove the protection from the adhesive. Stick the SADEV spacer on the edge of the glass, on the bottom right-hand corner flush with the glass.


The spacers have different functions:

- To have a regular space between the glass panels.


The spacers are 5 mm wide. If you need a larger gap, you can stick the spacers together to obtain spacings of 10, 15 mm....



THICKNESS SHIMS INSTALLATION









- 1 Put the glass on the outside
- 2 Insert the thickness shim between the glass and the wedge


Kit Reference	Glass composition	Glazing thickness	Put the thickness shim
0090SF-K12-0606	6.6	12.4 > 13.2 mm	А
0090SF-K12-0808	8.8	16.2 > 16.8 mm	А
		16.9 > 17.4 mm	No thickness shim
0090SF-K12-1010	10.10	20.2 > 20.8 mm	Α
00903F-K12-1010		20.9 > 21.6 mm	No thickness shim

G HIGH WEDGES INSTALLATION





1 - Insert the high wedge.Pay attention to the direction of the arrows.




- 2 Insert the screw in the provided place
- 3 Screw with the screwdriver to fix the glass.

Use the torque screwdriver (Ref.: 007-TRVS-2 NM) to control the tightening torque: 2 Nm.



CLADDING AND GASKET INSTALLATION ON THE ACCESSIBLE SIDE.





1 - Clip the cladding.




CAUTION:

Be sure to take into account the expansion gaps between the OSF profiles and the support.

MORE INFORMATION ON PAGE 6.






- 1 Add the press-in gasket between the cladding and the glass.
- 2 Do not stretch the gasket by clipping it.



The gasket must be correctly installed along the entire length of the cladding. It is advisable to align the junctions of the cladding with those of the rails.






- 1 Cleaning the rail with the Sadev cleaning set. Ref. : 70UT-KITNET before installing the end cap.
- 2 Remove the adhesive protection.
- 3 Press the end cap at the end of the rail.






U Profile




Tube with slot for glass







INSTALLATION OF HANDRAIL

Connector



Bracket






You have successfully assembled your balustrade!




REMOVING THE WEDGES


MAINTENANCE



 After removing the cladding and gasket, unscrew the screws 1 cm high.



2 - Apply a force on the screw in order to lower the intermediate wedge.



3 - Finish unscrewing the screw and remove it



4 - Using a screwdriver, pry between the intermediate and upper wedge to remove the high wedge.



4 - If thickness shims have been added, you can use pliers to remove them

INFORMATIONS

Once all the high wedges have been removed from the rail, remove the glass.

Replace all wedges. The wedges cannot be reused.

OSF[®]

Notes



otes	





ASSEMBLY GUIDE OSF PROFILE

Available on sadev.com Q

